

How to Set Up

1 Turn on your WiFi-To-Go

Push  or  button for about 5 seconds.




2 Choose ☒ GL06P... ☒ GL04P... for WiFi network on your device ☒ GP02...

Make sure WiFi is enabled.



3 Put the password back of the device (8-digits number)

It's ready to use when it shows like this. (on WiFi-To-Go)



* Display varies slightly from device to device.

Note

- Your mobile should be on "Flight mode" to avoid accidental-roaming.
- It gets disconnected automatically when you do not use it for a certain amount of time.
- To turn it off, push  or  button for about 5 seconds.
- Please be careful with battery life. Make sure it is fully charged when you go out.
- Please do not touch RESET button as it changes critical settings.
- In case the device stops working, email us with the condition details.
We will react immediately.